




DIGITAL WIRELESS CLOCK Installation Instructions (All Models: DWC-200, DWC-300, DWC-400, etc.)



12/24 Select - Removing the jumper will allow the clock to display time in a 24 hour format (0:00 thru 23:59)

Re-Transmit Select - Used to select the Re-Transmit.

- 9600 - No Re-Transmit
 - 4800/3 - Re-Transmit at x7 seconds (7, 17, 27, 37, 47, 57)
 - 2400/2 - Re-Transmit at x9 seconds (9, 19, 29, 39, 49, 59)
 - 1200/1 - Re-Transmit at x3 seconds (3, 13, 23, 33, 43, 53)
- (The interface Transmits at x5 Seconds (5, 15, 25, 35, 45, 55)

